



PIXEL
USER'S MANUAL
NÁVOD NA POUŽITIE



WARNING UPOZORNENIE



WHAT'S IN V BALENÍ




PIXEL

Silicone strap
Silikónový pásek


Micro USB cable
Micro USB kábel

Power button
Vypínač

Click to turn on, hold 1.5 s to turn off
Zapnutie stlačením, pre vypnutie podržte 1,5 sec.




SWITCHING THE LIGHTING MODE ZMENA REŽIMU SVIETENIA




LUMENS/RUN TIME VÝKON / ČAS SVIETENIA

MODE	BRIGHTNESS	LOW	MID	HIGH
	LUMENS	4	10	20
	h:min	07:00	02:40	01:25
	LUMENS	4	10	20
	h:min	13:05	07:20	05:40
	LUMENS	4	10	20
	h:min	21:40	10:35	06:20

HOW TO RECHARGE NABIJANIE



HOW TO INSTALL MONTÁŽ



SPECIFICATION ŠPECIFIKÁCIA

ANSI FL 1 STANDARD

